

Installation manual

Assembly & maintenance



Installation manual

Assembly & maintenance

Assembly of split sprocket body

Make sure to match the markings on the hub when mounting the two sprocket halves. Lubricate the bolts with copper paste and then screw them, together with Nord-Lock washers, into the hub. Follow Nord-Lock's torque guidelines when tightening the bolts.

Installation and rotation of wear parts

Always install the wear parts with new bolts and Nord-Lock washers. Lubricate both the contact surface of the wear parts and the bolts with copper paste. Follow Nord-Lock's torque guidelines when tightening the bolts.